



3990 Old Town Ave C-207  
San Diego, CA 92110

## Cleaning and Maintaining Your Designer Series™ Podium or Kiosk

### Cleaning Tips for Laminate

To clean the surface, use a damp cloth or sponge and a mild soap or detergent. Rinse thoroughly with warm water and wipe dry. Difficult stains such as coffee or tea can be removed using a mild household cleaner and baking soda; mixing to achieve a paste consistency. Use a stiff nylon bristle brush, scrubbing (approx. 15-20 strokes) the affected area. Do not scrub so as to mar (damage, scratch) the surface finish. Stubborn stains that resist any of the above cleaning methods may require the use of undiluted household bleach or nail polish remover. Use a cotton ball saturated with bleach or nail polish remover (acetone), gently rub the stain for up to two minutes. Rinse thoroughly with warm water and wipe dry using a soft cloth. This step may be repeated if the stain appears to be going away and the color of the laminate has not been affected.

**Warning:** Prolonged exposure of the laminate surface to bleach will cause discoloration. Always rinse laminate surfaces after cleaning! Failure to rinse after cleaning can cause damage; even if a small amount of cleaning solution remains on the surface. A dry residue may be invisible; however, moisture from cups or drinks can reactivate it, and result in permanently etched scars or stains over time.

Hot pans and heat-producing appliances (such as electric skillets), when set directly upon countertops, can mar the product's beauty. Always use a heat shield, hot pad or trivet.

**A Few Notes of Caution:** *Acidic or abrasive cleaners* can damage laminate surfaces; do not use them. Drain cleaners containing lye will permanently damage the laminate surface. If you spill a drain cleaner, wipe it up immediately and rinse several times with water. *Hair, textile and food dyes* can cause permanent stains. If dye should happen to spill, wipe it up immediately with dishwashing detergent or an all-purpose cleaner.

Do not work with *oven cleaners* on an unprotected countertop. Wipe spills away promptly and rinse several times with water. *Rust removers* contain harsh chemicals, which will quickly cause permanent damage. If a spill occurs, wipe off all residue immediately, wash thoroughly with soapy water and rinse several times. *Steel wool* and *other abrasive pads* will damage the laminate face. Do not use them for cleaning and don't store steel wool pads on your countertop; the metal can rust and leave stains. *Toilet bowl cleaners* contain harsh chemicals that can cause permanent damage. If spills occur, wipe up immediately, wash surface with soapy water and rinse several times.

## Recommended Household Cleaners:

- Formula 409
- Glass Plus
- Fantastik
- Windex
- Mr. Clean
- Isopropyl Alcohol (Isopropanol)

## Do Not use products that contain:

- Hydrochloric Acid
- Sulfuric Acid
- Hydrofluoric Acid
- Phosphoric Acid
- Sodium Hydroxide
- Pumice (abrasive)

Do not leave the kiosk or podium outside exposed to the elements. Any weather damage will be considered misuse

The above tips are a courtesy of [WilsonArt](#).